


Rittal – The System.

Faster – better – worldwide.

- Enclosures
- Power Distribution
- Climate Control
- IT Infrastructure
- Software & Services

Rittal – The System.

Faster – better – worldwide.



Sicherheitsverriegelung
Safety lock
Verrouillage de se'curite'
Veiligheidsvergrendeling
Säkerhetsförrigling
Blocco di sicurezza per
interruttore principale
Cierre de seguridad

SZ 2416.000
SZ 2418.000
SZ 2419.000

11/2011 A4570700SZ73 222861

Montage-, Installations- und Bedienungsanleitung
Assembly and operating instructions
Manuel d'installation et de maintenance
Montage- en bedieningshandleiding
Montage- och hanteringsanvisning
Istruzioni di montaggio e funzionamento
Instrucciones de montaje

RITTAL GmbH & Co. KG
Postfach 1662 · D-35726 Herborn
Phone +49(0)2772 505-0 · Fax +49(0)2772 505-2319
E-mail: info@rittal.de · www.rittal.com




ENCLOSURES POWER DISTRIBUTION CLIMATE CONTROL IT INFRASTRUCTURE SOFTWARE & SERVICES




FRIEDHELM LOH GROUP

ENCLOSURES POWER DISTRIBUTION CLIMATE CONTROL IT INFRASTRUCTURE SOFTWARE & SERVICES


FRIEDHELM LOH GROUP




TS/SE



1




2



5,5x13
Md= 5 Nm


75

3







5,5x13
Md= 5 Nm




4



min. 1,5



TS/SE




(B) = Montage/assembling SZ 4127.010

(1A) = (1) Seite 2 / page2


SE8: (A) entspr. Seite 2 montieren/assembling according page 2

3A





5,5x13
Md= 5 Nm

4A




min. 1,5



(B) SZ 4127.010



2A



75

5,5x13
Md= 5 Nm

R>= 350



(A)